

TTS Glow Wagons

(EL47587)

Getting started with your Glow Wagon

The Glow Wagons are robust, light up vehicles designed for use in early years settings and beyond. They are non-motorised and move when pushed or pulled, making them suitable for young children in their sensory, imaginative or small world play.

The Glow Wagons have been tested for ages **10 months upwards**.

What's included?

- 4 x Glow Wagons
- 4 x charging cables
- 1 x quick visual guide



First things first – charging the Glow Wagons

Before using the Glow Wagons, make sure they are charged.

Charging your Glow Wagons

- Plug the charging cable provided into the charging port underneath the wagon.
- Charge time: approximately 2 hours.
- A full charge provides around 3.5 hours of use.
- You will know that the wagon is charging as it will glow red.
- Once fully charged, the wagon will glow green.

Switching the Glow Wagon on and off

- To switch the Glow Wagon on, press and hold the white button on top of the wagon for 2 seconds.
- When switched on the Glow Wagon will go to the default colour (glow green or blue).
- Press and hold the same button for 2 seconds to turn the wagon off.

Using the colour modes

The Glow Wagons have two colour modes. These are:

Mode 1 – Movement activated colour change

In this mode, the colour of the wagon changes depending on how the wagon is moved.

- Roll the wagon forwards and it will glow green.
- Roll the wagon backwards and it will turn blue.

The wagons are non-motorised and move by being pushed or pulled.



Mode 2 – Fixed colour selection

This colour allows you to choose a set colour for your Glow Wagon.

- Continue to press the white button on top of the wagon to scroll through the colour options.
- There are 9 colour settings to choose from – 8 single colours followed by 1 multicolour mode where colours scroll continuously as the wagon is moved.
- Stop pressing the button when the desired colour is selected.
- The wagon can then be pulled or pushed while staying in the chosen colour mode.

Sleep mode

To save battery power, the Glow Wagon will automatically enter sleep mode after 5 minutes of inactivity. Press the white button on top to switch it back on.

Connecting Glow Wagons together

Each wagon has a tow bar at the front and a hook on the back. This allows multiple wagons to be linked together or can be used for joining other items.



Seating and compatibility with other glow resources

- The Glow Wagons feature two seats, one in front of the other. These are designed to be compatible with the Glow People.
- Glow People can be placed securely inside the wagon for imaginative and small world play.
- The wagons can also be connected to the Remote Control Light Up Vehicle, which can pull the wagons along.

Care and maintenance

- Clean the Glow Wagons using a soft, damp cloth.
- **Do not** submerge in water.
- Recharge regularly to maintain battery performance.

